

Motorola T5710 “Family Radios” Programming

Order	Function	Possible Settings	Default Setting	Default Display
1 st	Channel (Frequency)	1-22	Channel 10	10
2 nd	Interface Eliminator Code	0-38	Off	0
3 rd	Call Alert	0-10	Long ring	1 CA
4 th	Voice Activation (Headset)	1-3	Medium sensitivity	2
5 th	Qt Noise Filtering	Y or -	Off	Qt -

Talk Confirmation: To turn Talk Confirmation off (default mode), press and hold the + button while turning the radio on. Confirm that there is not a graphic in the upper right hand corner of the display when Talk Confirmation is off.

“Mon” Button: Holding it for several seconds will turn off the squelch and you will hear static. Use this feature when setting volume.

To scan: Push the “MON” button for 1 second.

To alert: Push the *button.

Locking the Keyboard: Push “MENU” for 3 seconds (default mode). A padlock graphic will appear in the display.

Channel	Frequency	Usage	Wattage	License Required?
1	462.5625 MHz	GMRS/FRS	1	yes
2	462.5875 MHz	GMRS/FRS	1	Yes
3	462.6125 MHz	GMRS/FRS	1	Yes
4	462.6375 MHz	GMRS/FRS	1	Yes
5	462.6625 MHz	GMRS/FRS	1	Yes
6	462.6875 MHz	GMRS/FRS	1	Yes
7	462.7125 MHz	GMRS/FRS	1	Yes
8	467.5625 MHz	FRS	.5	No
9	467.5875 MHz	FRS	.5	No
10	467.6125 MHz	FRS	.5	No
11	467.6375 MHz	FRS	.5	No
12	467.6625 MHz	FRS	.5	No
13	467.6875 MHz	FRS	.5	No
14	467.7124 MHz	FRS	.5	No
15	462.5500 MHz	GMRS/FRS	1	Yes
16	462.5750 MHz	GMRS/FRS	1	Yes
17	462.6000 MHz	GMRS/FRS	1	Yes
18	462.6250 MHz	GMRS/FRS	1	Yes
19	462.6500 MHz	GMRS/FRS	1	Yes
20	462.6750 MHz	GMRS/FRS	1	Yes
21	462.7000 MHz	GMRS/FRS	1	Yes
22	462.7250 MHz	GMRS/FRS	1	yes